



EXHIBIT ST-1
BROOKVILLE - TAMPA BAY REGIONAL AIRPORT
 Track Diagram
 Brooksville, FL
 MP SR 806.01

PAGE 1 OF 1

NOTE: The track diagram above was created using scaled aerial imagery. Any and all track stationing/measurements are approximate and should not be relied upon for any engineering or construction purposes. For illustrative purposes only.

DRAWN BY: RSF

CSX966035

DATE: 8/19/2022

